


ANYCUBIC Photon M3 Plus

Product Description



9.25

6K Monochrome Screen

34µm accuracy.



Anycubic LighTurbo

Strong light power.




Anycubic Cloud

One touch printing.



Smart Resin Filling

Rest without worries.



Technical Specifications

- Exposure screen: 9.25 inch monochrome screen
- Printing volume: 5.9 liters / 199.1 ounces
- Print size: 24.5 x 19.7 x 12.2 cm / 9.6 x 7.8 x 4.8 inches (HW)
- Printing platform: Laser engraved aluminum alloy platform
- Light source: Parallel matrix light source (40 LED beads)
- Machine leveling: 4-point manual leveling
- Printing accuracy: 6K (5,760 x 3,600 pixels)
- Printing speed: ≤10cm/hour
- Control panel: 5-inch resistive touch screen
- Data input: USB-A 2.0 & 3.0 interface
- Power supply: On/Off switch
- Rated power: 144W
- Machine dimensions: 47.5 x 36 x 29 cm (HW)
- Machine weight: ~12kg




Well-defined Details

Equipped with a 9.25" 6K exposure screen, the printer provides a large print size of 245*197*122mm and high accuracy of 34µm. The high-precision Z-axis ball screw combined to deliver fine details.



Anycubic Cloud

Support "USB-A 2.0 / LAN / WAN" and USB-A 3.0 / LAN/WAN control mode. No matter file transfer or printing, you can realize that just by one touch on [Anycubic Cloud](#).




Smart Resin Filling

The new automatic feeding function automatically feeds the resin vat when resin is insufficient and stop when resin is enough.



Foundation Is the Key

The laser engraving pattern after repeated designs and tests greatly increases the adhesion at the bottom of the platform and improves the printing success rate.




Speed Up Your Experience

The self-developed Anycubic LightTurbo features matrix-arranged LCD beads, which provide strong light power, making high-speed printing possible.




Sharpen Your Prints

The screen contrast ratio is as high as 350:1, 75% higher than that of competitive products (200:1), greatly improving printing details.



Every Minute Counts

The maximum printing speed can reach up to 100mm / h. It takes only 1.2 hours to print a 12 cm high model, saving 1.8 hours compared with 3 hours of competitive products.



Protect What Matters

An extra anti-scratch film is included in the printer to protect the valuable 9.25-inch 6K screen and make the printing more relaxed.



Large Touch Screen

The printer is equipped with a 5-inch LCD touch screen, which is very sensitive to response and brighter in color, offering better using experience.

Parts List



User manual



Funnel



Tool set



Scraper



Resin vat



Platform



Power cord



WIFI



Mask



Glove



Screws



USB
memory



Screen
protector



Levelling
paper



Auto-feed
unit