


# ANYCUBIC Photon M3



**4K + Monochrome Screen**  
Bigger LCD screen, greater Freedom.




**Fast Print Speed**  
50mm/hour.



**Larger Printing Volume**  
180x163.9x102.4mm.




**Laser-engraved Build Plate**  
Experience High rates of success.



## Technical Specifications

- LCD screen: 7.6 inches monochrome screen
- Printing accuracy: 4,096 x 2,560 pixels
- Printing volume: 2.99 l / 101.19 oz
- Light transmittance: 4%
- Contrast ratio: 400:1
- Light source: parallel matrix light source
- Printing platform: laser-engraved aluminum alloy platform
- Printing speed:  $\leq 5$  cm / 1.97 inches per hour
- Control panel: 2.8-inch resistance touch screen
- Data input: USB-A 2.0 interface
- Rated power: 55W
- Print size: 18.0 x 16.3 x 10.2 cm / 7.1 x 6.4 x 4.0 inches
- Machine size: 42.5 x 26.9 x 25.6 cm / 16.7 x 10.6 x 10.1 inches. (HLW)
- Machine weight: 7 kg / 15.4 LBS




### Unleash Your Imagination

With a 7.6-inch high quality monochrome screen, the printing volume of Anycubic Photon M3 is up to 180×163.9×102.4mm.




### Sharpen Your Mind

Ultra-high resolution of 4,096 x 2,560 pixels. It is capable of producing parts with high dimensional accuracy and intricate detailing.




### Foundation Is the Key

The new build plate has a texturized checkerboard pattern that dramatically improves adhesion and print success rate.




### Ultra Fast Printing

The fastest printing speed can reach 50mm/h, and it only takes 2.5 hours to print the 12cm high miniature, which is 30 minutes less than the 3 hours of the competitive products.



### Sharp & Clear Edges

The printer adopts an LCD screen with 400:1 contrast, 100% higher than its competitor. The high contrast leads to parts with better surface finish.




### Powerful Enlighting Matrix

With the Anycubic LightTurbo matrix light source system, the matrix LED beads will provide strong light energy, making high-speed printing possible.




### Protect What Matters

The anti-scratch protective film greatly extends the lifespan of the LCD screen.



### Fully Compatible Slicer

Fully compatible with all Anycubic resin printers. It is easy to use and offers versatile and professional service without monthly fees.



### User-friendly Interface

More convenient and intuitive to operate and make the parameter adjustment.

## Parts List



Funnel



Glove



Mask



Screen protector



Platform



Power-cord



Resin vat



Levelling paper



Scraper



USB memory



User manual



Tool set